

Pro-face

GP Series

CA1-PFSALL-21 (Profibus-DP Slave I/F Unit for GP2000)



User' s Manual

Pro-face Europe B.V.

Table of Contents

Table of Contents	2
Essential Safety Precautions	3
Note on CE Marking	3
Package Contents	3
Chapter 1 – Introduction	
CA1-PFSALL-21 Unit Specifications	4
External Dimensions	8
Component Names and Functions	9
Installation	10
Chapter 2 – Operation	
Connectable GPs	11
Cable Diagram	12
Configuration as a Profibus-DP Slave	13
Chapter 3 – Diagnostics	
Error Diagnostics	14

Essential Safety Precautions

This manual includes procedures that must be followed to operate the CA1-PFSALL-21 Unit and GP correctly and safely. Be sure to read this manual and any related materials thoroughly to understand the correct operation and functions of the CA1-PFSALL-21 Unit and GP.

- To prevent Internal Damage or Malfunction of the CA1-PFSALL-21 Unit:
 - Be sure to use the CA1-PFSALL-21 Unit only within its designated operating temperature range. Operating the CA1-PFSALL-21 Unit outside this range can lead to breakdown or malfunction.
 - Be sure that water, liquids or metal particles do not enter the CA1-PFSALL-21 Unit, since it may cause the unit to malfunction, or can lead to an electric shock.
 - DO NOT store the CA1-PFSALL-21 Unit in a place where it will be exposed to direct sunlight, high temperatures, excessive dust or vibration.
 - The CA1-PFSALL-21 Unit is a high precision piece of equipment. DO NOT subject it to excessive shocks.
 - DO NOT store the CA1-PFSALL-21 Unit near chemicals, or where chemicals can come into contact with the unit.

CE Marking

The CA1-PFSALL-21 is a CE marked product that conforms to EMC directives EN55011 class A and EN61000-6-2 .


Package Contents

The CA1-PFSALL-21 Unit' s packing box contains the items listed below. Please check to confirm that all the items shown below have been included.

**CA1-PFSALL-21
(Profibus-DP Slave I/F)**



**CA1-PFSALL-21
User' s Manual**



This unit has been carefully packed, with special attention to quality. However, should you find anything damaged or missing, please contact your local GP distributor immediately for prompt service.

Chapter 1 – Introduction

1.1 CA1-PFSALL-21 Unit Specifications

1.1.1 General Specifications

	CA1-PFSALL-21
Power Supply	DC5V
Max Power Consumption	350mA (Max)

When used with the models GP2300-TC41/LG41-24V, GP2301-LG/SC41-24V:

	GP2300 Series + CA1-PFSALL-21
Rated Voltage	DC24V
Power Supply	DC19.2V ~ DC28.8V
Max Power Consumption	24W (Max)
Voltage Endurance	AC1000V 10mA for 1 minute (between charging and FG terminals)
Insulation Resistance	DC500V 20M Ω or higher (between charging and FG terminals)

When used with the models GP2400-TC41:

	GP2400 Series + CA1-PFSALL-21
Rated Voltage	DC24V
Power Supply	DC19.2V ~ DC28.8V
Max Power Consumption	30W (Max)
Voltage Endurance	AC1000V 10mA for 1 minute (between charging and FG terminals)
Insulation Resistance	DC500V 20M Ω or higher (between charging and FG terminals)

When used with the models GP2500/2600-TC41-24V, GP2501-LG/SC41-24V:

	GP2500/2600 Series + CA1-PFSALL-21
Rated Voltage	DC24V
Power Supply	DC19.2V ~ DC28.8V
Max Power Consumption	52W (Max)
Voltage Endurance	AC1000V 10mA for 1 minute (between charging and FG terminals)
Insulation Resistance	DC500V 20MΩ or higher (between charging and FG terminals)

1.1.2 Environmental Specifications

	GP2000 Series + CA1-PFSALL-21
Ambient Operating Temperature	0 °C to 50 °C
Ambient Storage Temperature	-20 °C to 60 °C
Operating Humidity	10%RH to 90%RH (no condensation)
Operating Atmosphere	Must be free of corrosive gasses
Grounding	100Ω or less grounding resistance
Vibration (Non Continuous)	10~57Hz 0.075mm, 57~150Hz 9.8m/s ²
Vibration (Continuous)	10~57Hz 0.035mm, 57~150Hz 4.98m/s ²

1.1.3 External Specifications

CA1-PFSALL-21:

	CA1-PFSALL-21
External Dimensions	109.9mm (W) x 105mm (H) x 19.0mm (D)
Weight	145g or less
Attachment Method	Attached to the back of GP

CA1-PFSALL-21 Module + GP Main Unit:


	CA1-PFSALL-21 + GP2300 Series	CA1-PFSALL-21 + GP2400 Series	CA1-PFSALL-21 + GP2500 Series	CA1-PFSALL-21 + GP2600 Series
External Dimensions	171mm (W) x 138mm (H) x 79 mm (D)	215mm (W) x 170mm (H) x 79 mm (D)	317mm (W) x 243mm (H) x 77 mm (D)	317mm (W) x 243mm (H) x 77 mm (D)
Weight	1245 or less	2645g or less	3645g or less	3645g or less
Attachment Method	Mounted in a solid enclosure			
Cooling Method	Natural Air Circulation			

1.1.4 Profibus-DP Specifications


	GP377-PF21
Protocol	PROFIBUS EN50170 & DIN 19245 Part 1
Medium	EIA RS485 twisted pair cable
Cable Type	Wire Gauge: 0.64mm Conductor Area: > 0.34mm ²
Supported Baud Rates	9.6, 19.2, 45.45, 93.75, 187.5, 500, 1500, 3000, 6000, 12000 kbit/s
Length of Cable*	1200m @ 9.6 ~ 93.75 kbit/s extendible with repeaters 1000m @ 187.5 kbit/s extendible with repeaters 400m @ 500 kbit/s extendible with repeaters 200m @ 1.5 Mbit/s extendible with repeaters 100m @ 12 Mbit/s extendible with repeaters * Valid for the Cable Type as specified above
Number of Nodes	32 Max in one segment, 127 possible with repeaters (Including Master)
I/O per Slave	128 Bytes Input Max (= 64 Words Max) 128 Bytes Output Max (= 64 Words Max)

1.2 External Dimensions

The CA1-PFSALL-21 Unit's external dimensions are as follows:
(Unit: mm)



1.2 Component Names and Functions



Notes:

NODE ID: This is coded in Hexadecimal, e.g. GP as slave No.1 => 01 (HIGH:0, LOW:1), GP as slave No.31 => 1F (HIGH:1, LOW:F).

TERM: The first and last nodes on the Profibus-DP network should have their termination switched on. Many Profibus-DP connectors have a built-in TERM switch, then the GP377-PF21 TERM should be switched to the OFF position.


PWR led: Module Power indicator (see diagnostic section)

ERR led: Network Error Status indicator (see diagnostic section)


1.4 Installation

WARNING: Prior to installing the CA1-PFSALL-21 Unit, be sure to check that the GP' s power is OFF. Otherwise, it can cause an electric shock.

1. Remove the GP unit' s expansion interface' s protective cover.



2. Secure the CA1-PFSALL-21 Unit in place with its four (4) attachment screws (see figure). A torque of only 0.5 to 0.6 Nm is needed.



Chapter 2 – Operation

2.1 Connectable GPs

2.1.1 Connectable “Medium” Size GPs:

GP2301-LG41-24V
GP2301-SC41-24V
GP2300-LG41-24V
GP2300-TC41-24V
GP2400-TC41-24V
GP2501-LG41-24V
GP2501-SC41-24V
GP2500-TC41-24V
GP2600-TC41-24V




Note: CA1-PFSALL-21 Connects directly to the back of the bus connector on the GP

2.2 Cable Diagram

2.2.1 Cable Diagram:

The CA1-PFSALL-21 Profibus-DP Slave units are connected via RS485 2-Line connections. Please use the cable type as recommended in section 1.1.4. Below is an example of wiring between two Profibus-DP Nodes.



2.3 Configuration as a Profibus-DP Slave

2.3.1 Introduction to Profibus-DP:

Profibus-DP is a field bus network for control of remote I/O by a master (typically a PLC). The master on the Profibus-DP network reads input and writes output data to all the slaves on the network. The CA1-PFSALL-21 Unit is a Profibus-DP Slave. It enables a GP to connect to a Profibus-DP network as a slave hence it is treated by the Profibus-DP master as remote I/O.

2.3.2 Profibus-DP Master Configuration:

Each slave on the Profibus-DP network has to be entered into the Profibus-DP master's configuration. Here is defined the Input and Output size that the slave will occupy and the Node ID for the slave. For this purpose each slave requires a unique "GSD" file. This is an electronic description of the slave device. The CA1-PFSALL-21 has a GSD file also. The name is: GPE12982.GSD. This file can be found in the GP-PRO/PBIII for Windows European Software v5.0 or later, otherwise please contact your local Pro-face Supplier.

2.3.3 GP Configuration:

The Node ID has to be set on the CA1-PFSALL-21 module. This should be set to match the Node ID assigned to it by the Profibus-DP master. Please note that the Node ID on the CA1-PFSALL-21 is represented in Hexadecimal. Only the range 01h ~ 7Eh (1~126 decimal) are valid.

The Input & Output area size on the GP have also to match what was assigned by the Profibus-DP master. These have to be configured using the GP-PRO/PBIII for Windows Software. Please see the "PLC Connection Manual" and the documentation on the CD-ROM for instructions.

Chapter 3 – Diagnostics

3.1 Error Diagnostics

3.1.1 Status LEDs:



PWR LED Status	ERR LED Status	Error	Cause & Remedy
OFF	OFF	No Power to the Profibus Module.	<ol style="list-style-type: none"> 1. Module not connected properly to the bus connector on the GP. Please check that the mounting screws are fixed firmly. 2. Module damaged. Contact your Pro-face dealer. 3. GP damaged. Contact your Pro-face dealer.
ON (Green)	ON (Red)	Profibus-DP Network Error.	<ol style="list-style-type: none"> 1. Profibus-DP Master configuration not present. Verify that the GP slave with the error has been entered in the master's configuration and that the correct GSD file has been used. 2. Node ID incorrect. Set the Node ID on the module to match the master's configuration. 3. Cable Error. Verify that the cable is connected properly to the GP unit and the wiring is correct. 4. I/O Size Error. Verify that the GP's I/O size matches with that configured by the master. 5. Termination incorrect. Verify that the termination is only ON for the first and last nodes. If the bus connectors have a termination switch then turn the termination OFF for all GPs.
ON (Green)	OFF	No Error	Module and Profibus -DP network configuration are OK !

3.1.2 GP Error Codes:

Error Code	Error Description	Cause & Remedy
02:14	Interface Module Hardware Error	<ol style="list-style-type: none"> 1. Interface module incorrect type. Please replace. 2. Interface module not connected. Securely mount the module with the 3 mounting screws. 3. Interface module damaged. Contact your Pro-face supplier.
02:FF	Data Send Timeout	<ol style="list-style-type: none"> 1. GP unable to send data. Check that the cables are connected correctly and that the master is running.
02:FE	Date Receive Timeout	<ol style="list-style-type: none"> 1. Cable error. Check Cable is correct and connected correctly. 2. PLC in stop mode. Data cannot be received by the GP while the PLC is in stop mode. 3. Profibus-DP network not active. 4. Interpreter function block (FB99) not present or not called in PACKET TRANSFER mode. Check PLC program.
02:FC	Protocol Error	<ol style="list-style-type: none"> 1. Illegal Data Received by the GP in PACKET TRANSFER mode. Check the PLC program and for bad cables or noise on the bus.
02:FD	Data Error	<ol style="list-style-type: none"> 1. Illegal Data Received by the GP in PACKET TRANSFER mode. Check the PLC program and for bad cables or noise on the bus.
02:FA	Address out of range error	<ol style="list-style-type: none"> 1. Illegal address being accessed by GP. Check that the address type exists and that the range is supported by the PLC

**Pro-face European Headquarters**

Pro-face HMI B.V.
Amsteldijk 166
1079 LH Amsterdam
The Netherlands
Tel: +31 (0)20 6464 134
Fax: +31 (0)20 6464 358
<http://www.proface.com>
info@proface.com

Pro-face France

Pro-face France S.A.S.
Le Vinci 1, rue Henri Becquerel
77290 Mitry-Mory
France
Tel: +33 (0)1 60 21 22 91
Fax: +33 (0)1 60 21 22 92

Pro-face Germany

Pro-face Deutschland GmbH
Albertus Magnus Strasse 11
42719 Solingen
Germany
Tel: +49 (0)212 258 260
Fax: +49 (0)212 258 2640

Pro-face Italy

Pro-face HMI B.V. Italy
Via Carcano 44
20033 Desio (MI)
Italy
Tel: +39 0362 33 71 63
Fax: +39 0362 30 77 25

Pro-face Scandinavia

Pro-face Scandinavia ApS
Copenhagen Europe Center
Vesterbrogade 149
DK-1620 Copenhagen V
Denmark
Tel: +45 (0)33 27 0616
Fax: +45 (0)70 27 0506

Pro-face UK

Pro-face UK, Ltd.
The Venture Centre, The Science Park
Coventry CV4 7EZ
United Kingdom
Tel: +44 (0)2476 692363
Fax: +44 (0)2476 692365

Manual: CA1-PFSALL-21-MAN-E01